
Entering Conditions for Contact ID

When entering Contact ID conditions, you must define the following:

- The zones that will be reporting (with partitions, if used)
- The events that will be reported for these zones

If you are setting up a Burglar system with 3 zones:

Zone 001 – Front Door

Zone 002 – Motion Detector

Zone 003 – Back Door

you would have to enter the event code for a Burglar alarm (see CID Table) for these three zones:

Event Qualifier Code	Event Code	Partition/ Area Code	Zone/Contact/Sensor Code	Event Description/ Internal Code	Callback Option	Authority Name/Sensor Location	Authority Phone #1	Authority Phone #2
E	134	01	001	001	0	Front Door	101-111-0101	
E	132	01	002	001	0	Motion Detector	101-111-0101	
E	134	01	003	001	0	Back Door	101-111-0101	

To make the entry of these conditions even easier – or if you are unsure of exactly which specific Contact ID code will come in (i.e., 131 vs. 135), you could enter these same conditions, using wildcards, as such:

Event Qualifier Code	Event Code	Partition/ Area Code	Zone/Contact/Sensor Code	Event Description/ Internal Code	Callback Option	Authority Name/Sensor Location	Authority Phone #1	Authority Phone #2
E	13?	??	001	001	0	Front Door	101-111-0101	
E	13?	??	002	001	0	Motion Detector	101-111-0101	
E	13?	??	003	001	0	Back Door	101-111-0101	
